POSITEK LIMITED

Installation Information

LIPS® A133 MID STROKE LINEAR POSITION SENSOR

INTRINSICALLY SAFE FOR HAZARDOUS MINING ENVIRONMENTS

ANZEx Qualified to Intrinsic Safety Standard Certificate numbers ITACS ANZEX 07.4039X			Ex ia I/IIC T4 (Ta = -40°C to +80°C)
Electronics Version	**Output Description:**	**Supply Voltage:** V_s (tolerance)	**Load resistance:**
EX03	0.5 - 4.5V (ratiometric with supply) [Output code 'A']	+5V (4.5 - 5.5V)	5kΩ min

Connector Pin Layout:
IEC 60947-5-2



Putting Into Service: The sensor must be used with a galvanic isolation barrier designed to supply the sensor with a nominal 5V and to transmit the sensor output to a safe area. The barrier parameters must not exceed:-

Ui = 11.4V	**Ii = 0.46A**	**Pi = 0.51W**	
Ci = 1.56µF*	**Li = 150µH***	('Lxx' option)	*Figures for 150m cable
Ci = 1.01µF	**Li = 50µH**	('J' option	

The sensor is certified to be used with up to **150m** of cable, cable characteristics must not exceed:-

Capacitance:		max. total of:	550 nF
Inductance:	≤ 660 nH/m	for max. total of:	100 µH

Approval only applies to specified ambient temperature range and atmospheric conditions in the range: 0.80 to 1.10 Bar, oxygen ≤ 21%.

The performance of the sensor may be affected by voltage drops associated with long cable lengths; For cable lengths exceeding 10 metres a five wire connection is recommended to eliminate errors introduced by cable resistance and associated temperature coefficients.

N.b. sensors supplied with cable, the free end must be appropriately terminated.

Warning - The M12 IEC 60947 connector may be rotated for purposes of convenient orientation of the connector and cable, however rotating the connector more than one complete revolution is not recommended.
Repeated rotation of the connector will damage the internal wiring!

Use: The sensor is designed to measure linear displacement and provide an analogue output signal.

Assembly and Dismantling: The unit is not to be serviced or dismantled and re-assembled by the user.

Maintenance: Accumulated dust layer must not exceed a depth of 50 mm.

Mechanical Mounting: Via the two slots in the flange, the slots are 4.5 mm by 30 degrees wide on a 48 mm pitch.

Output Characteristic: Plunger extended 28 mm from mounting face at start of normal travel. Note: where dome end option is fitted add 5 mm. The output increases as the plunger extends from the sensor body, the calibrated stroke is between 51 mm and 100 mm.



Incorrect Connection Protection levels: Not protected – the sensor is **not** protected against either reverse polarity or over-voltage. The risk of damage should be minimal where the supply current is limited to less than 50mA.

For further information please contact:
www.positek.com sales@positek.com
Tel: +44(0)1242 820027 fax: +44(0)1242 820615
Positek Ltd, Andoversford Industrial Estate, Cheltenham GL54 4LB. U.K.